

64E4 Cultural Center TECH SPECS

Last Update August 30, 2013

Theater Address: 64 East 4th St, New York, NY 10009

Mailing Address: 64 East 4th St, New York, NY 10009

General

64E4 Cultural Center is a flexible black box theater with 2 spaces Theater 1 seats up to 72 seats. Theater 2 seats up to 40

Dimensions:

Theater One (Upper level)

North-South:

East-West:

Proscenium:

Thrust:

Height:

Upstage-Front Row playable space: 20'(w) x 18'-21'(d)*

Upstage-Front Row playable space: 25'(w) x 12.5'(d)

*based on 72 seats or 60 seats setup

To Ceiling: 12'5"

To Grid: 11'2"

To Duct: 9'8"

Theater #2 (Lower level)

North-South:

East-West:

Height:

To Ceiling:

To Grid:

To Duct:

Box Office: The Box Office is located at deck level on the 1st Floor.

Technical Booth:

Multiple power outlets, telephones, and desk space to accommodate production crew.

Dressing Rooms: There are two (4) person dressing rooms at basement level, backstage in the basement. The stage manager will be provided with keys to lock and unlock the dressing rooms.

Loading In/Out

Load in through lobby

- Building entrance 7'5"(h) x 5'8"(w)

64E4 Cultural Center does not have a loading bay, so all load-ins and load-outs must be done in the lobby of the building. This imposes a few restrictions

-Architectural finishes in the lobby and hallway must need to be protected. (Packing blankets & masonite available.)

-Since the load-in area is on the street, parking schedules should be carefully coordinated.

Stages

Stage Deck:

Masonite: Fastening to deck is allowed only under theater Staff supervision with prior approval. Upon strike all holes must be filled and painted

64E4 Cultural Center TECH SPECS

- Workspace: There is no separate workshop space, so sets should arrive ready to be assembled. Modification is possible in the space, but sawing or welding must first be approved.
- Painting: Requests to paint the deck/walls must be submitted in advance to Technical Manager. Upon Strike theater must be painted back* (* Walls Paint color - Behr UL160-23D Floor Behr - Jet Black Semi-Gloss NO EXCEPTIONS)
- Marley: Marley is not available for 64E4 Cultural Center. When it is down, nothing may be screwed into deck through marley. Tap shoes, sharp points, or other damaging equipment may not be used.
- F/X: Please inform us immediately if any fog, cigarettes, open flames (including candles and matches) or other f/x are required for the 4 production. Material data sheets and descriptions for any and all permits required by the NYC and its agencies must be provided six weeks prior to company's arrival.
- Flame proofing: Certificates for all materials and scenery *must* be provided before they enter the building.
- Projection: There is a chief mount to attach your projector.

Rigging:

64E4 Cultural Center is equipped with a pipe grid. There is an AC duct on the West wall that lowers the grid. Grid is rated for 30lbs/linear foot dead load. No live/dynamic loads from grid.

All rigging plans must be submitted six (6) weeks prior to your load-in, and are subject to approval.

Support:

Ladders

(1) 8' Ladder

(1) 10' Ladder

Use of Toxic and/or Hazardous Materials

Please be advised that the use of Toxic and/or Hazardous materials, including but not limited to:

- Flammable Materials
- Spray Paints (other than acrylic or water based)
- Acetone or other solvents
- Petroleum based products
- Non-water based adhesives

is forbidden in any interior space of 64E4 Cultural Center without the express written, advanced notice of the theater management. Permission will only be granted upon review of the material and implementation of proper protective procedures.

This policy will be strictly enforced and applies to the entire renting company.

64E4 Cultural Center TECH SPECS

Lighting:

The lighting system consists of

Theater One (Upper level)

INSTRUMENTS:

- 5 ELED Fresnel II/ 100W lamp/ 10° to 50° Manual zoom/ 5 pin DMX data input & output/ Edison connector
- 10 ELED Par RGB Zoom/ 80W lamp/ 10° to 60° motorized zoom/ 3-pin DMX serial input/output/ Edison connector
- 27 SF Zoom 25/50 degree/ 575W / Stage pin connectors
- 7 36 degree SF 575W / Stage pin connectors

TOTAL INSTRUMENTS = 49

CABLE

- 20 5' Jumpers/ stage pin connectors
- 18 10' Jumpers/ stage pin connectors
- 2 25' Jumpers/ stage pin connectors

TOTAL CABLE: 40

CONTROL AND DIMMERS

- 48 2.4K ETC Unison dimmers
- 48 Circuits on grid/ 12 Pigtail boxes w/4 circuits each
- 3 Edison outlet boxes (2 outlets each) with signal outputs for LED lights
- 1 ETC Element 60/500 Lighting console w/ cover
- 2 LCD Monitors for Lighting console w/cover
- 4 25' DMX data cables
- 10 10' DMX data cables
- 5 5' DMX data cables for ELED Fresnels
- 10 10' DMX 3 pin female/ 3pin male cable for ELED Pars
- 10 DMX Adapters 3pin male to 5pin female
- 10 DMX Adapters 3pin female to 5pin male

ACCESORIES

- 27 7 1/2" gel frames for SF Zooms
- 7 6 1/4" gel frames for 36 degree SF
- 5 7 3/4" gel frames for ELED Fresnels
- 49 Safety cables
- 5 Barndoors for ELED Frenels

- No food or drinks are allowed in the theater/ lighting booth.
- Please clear the show on the console after rental period is over.

All lights have working lamps and they must be returned in the same condition. We don't provide spare lamps.

If the renter want's to bring in more equipment, the list has to be approved by Choicircitati before load in. Renters are not allowed to bring additional instruments without approval.

If you need more information on the lighting console you can download the manual from the Internet.

Please note that we don't have Edison jumpers in our inventory. Renters need to bring those if needed.

There are three circuit/Net boxes mounted to the SL wall at grid height. Each box has 2 dedicated non-dims and one DMX port. All three ports are on Universe 3. These net boxes are to be used for the LED lights.

64E4 Cultural Center TECH SPECS

The non-dim circuits located on the ceiling of the theater are controlled by circuit breakers in the booth (#30, 32, 34, 36, 38, & 40). They are labeled.

The console must be connected to the control box located in the corner of the booth by both DMX port 1 and the network port in order for the entire system to function.

The LED fixtures will need to be prepped (DMX mode and address set) prior to hang. If you need more information on these fixtures please download the manual from the Internet.

Please be careful when hanging anything on the grid as the main circuit cables are directly attached to the grid. Circuit boxes can't be moved from their actual positions. You can't hang anything over the multi cable, on the sprinkler pipes, nor the black electrical conduit.

At the end of the rental we will check out the inventory with the renter. Any missing or damage items will be deducted from the security deposit at market value.

The renter needs to make sure during load not to leave on the grid any tapes, tie lines, cables etc. that were load in for the rental period. The grid should be returned in the same condition it was given to the renter.

Theater #2 (Lower level)

INSTRUMENTS:

- 4 ELED Fresnel II/ 100W lamp/ 10° to 50° Manual zoom/ 5 pin XLR data input & output/ Edison connectors
- 8 ELED Par RGB Zoom/ 80W lamp/ 10° to 60° motorized zoom/ 3-pin XLR serial input/output/ Edison connectors
- 9 50 degree SF 575W / Stage pin connectors
- 11 36 degree SF 575W / Stage pin connectors

TOTAL INSTRUMENTS = 32

CABLE

- 15 5' Jumpers/ Stage pin connectors
- 10 10' Jumpers/ Stage pin connectors
- 2 25' Jumpers/ Edison connectors

TOTAL CABLE: 27

CONTROL AND DIMMERS

- 5 Scrimmer Sticks dimmers with 4 600W circuits each for a total of 20 dimmers
- 1 ETC Express 48/96 lighting console with cover
- 1 Monitor with cover
- 1 Distribution box located at booth
- 2 25' DMX data cables
- 5 10' DMX data cables
- 4 5' 5 pin XLR data cable for LED Fresnels
- 8 5' 3 pin XLR data cable for LED Pars
- 7 DMX adapter 3pin male to 5pin female
- 3 DMX adapter 3pin female to 5pin male

64E4 Cultural Center TECH SPECS

ACCESSORIES

20	6 ¼" gel frames for SF
4	7 ¾" gel frames for ELED Fresnels
32	Safety cables
4	Barndoors for ELED Fresnels

- No food or drinks are allowed in the theater/ lighting booth.
- Please clear the show on the console after rental period is over.
- We don't provide spare lamps or diskettes.

**The theater power can't sustain more lighting instruments/ dimmers than the ones provided. We won't allow additional lighting equipment except for low wattage practicals.

The renter is responsible for the equipment. Any missing parts or units have to be replaced prior to load out date. All lights have working lamps and they must be returned in the same condition.

If you need more information on the lighting console you can download the manual from the Internet.

Please note that we don't have Edison jumpers in our inventory. Renters need to bring those if needed.

The LED fixtures will need to be prepped (DMX mode and address set) prior to hang. If you need more information on these fixtures please download the manual from the Internet.

At the end of the rental we will check out the inventory with the renter. Any missing or damage items will be deducted from the security deposit at market value.

The renter needs to make sure during load not to leave on the grid any tapes, tie lines, cables etc. that were load in for the rental period. The grid should be returned in the same condition it was given to the renter.

64E4 Cultural Center TECH SPECS

Sound:

All audio cables running from speakers/grid to the booths are color coded. For detailed information, see the respective theater's Speaker Positioning and Color Coding Plot.

The sound system consists of

Theater One (Upper level)

EQUIPMENT:

- 1 Mackie DL1608 Mixer
- 1 Mackie Accessories (DL1608 mixer manual. Pad lock & key)
- 1 Pyle Pro 8 channel amp PT800
- 6 Pyle pro speaker cabinets
- 2 Stageworks speakers (in closet)
- 1 M-Audio Subwoofer, SBX10
- 1 iPad, 3rd Generation
- 1 iPad charger (USB cable and wall adaptor) 1
- 1 M-Audio S.W mute pedal. (In plastic package)

CABLE & ACCESSORIES

- 4 Male XLR to female 1/4 turnarounds
- 1 Male 1/4 to female XLR turnaround
- 1 Male 1/4 to female 1/8 adaptor
- 1 Male XLR to Male XLR turnaround
- 1 Hosa Cable Pro-Conex Little Bro 8 inputs Live Audio Snake
- 1 S.W Power a/c cable
- 1 TRS to 1/8 inch cable
- 2 Female XLR to RCA cables
- 1 Single TRS to single XLR 100 ft cable (for subwoofer)
- 2 Dual TRS to RCA cables
- 8 Color coded grid cabling: 6 cables connected to speakers & 2 cables on grid to be used stageworks speaker cabinets when live, floor monitors are required.
- 4 Spansets
- 12 Ratchet straps

Theater #2 (Lower level)

INSTRUMENTS:

- 1 Sony STR DE197 Amplifier
- 2 JBL jet black speakers
- 2 Pyle Pro cabinet speakers

CABLE & ACCESSORIES

- 1 1/8 to RCA cable
- 2 Color coded grid cabling:
- 2 Spansets
- 6 Ratchet straps

The renter is responsible for the equipment. Any missing parts or cable must be replaced prior to load out date.

64E4 Cultural Center TECH SPECS

For assistance, please contact:

64E4
64 East 4th St.
New York, NY 10009
(212)505-6757

CHOICES/PARADISE
theater@paradisefactory.org

Tom Noonan
Artistic Director
tom@tomnoonan.com
Talia Lugacy
lugacy@gmail.com

CIRCULO
José Cheo Oliveras
Executive Director
joliveras@teatrocirculo.com
(917) 657-3057 (voice)


IATI
Winston Estevez
IATI Theater Artistic Director
(voice)

Pope Jackson
Technical Manager
Pope@ActuatorInc.com
(646) 708-5687

Speaker Positioning and Color Coding Plot

Choircirciati, Theater #1

64 E 4th Street, New York, 10003



Speaker Positioning and Color Coding Plot

Choicirciati, Theater #2

64 E 4th Street, New York, 10003

